MS99



30 V DC and lower rated voltage specification only

CE



MS99

(Example) Opening/closing capability None Standard specification 30 V DC and lower rated voltage specificatio V Upright orientation Н Horizontal Precision machine manufacturing Building air conditioning control Unit D Pa Е kPa Range Maximum scale value Detection of clogging of air filter Room pressure measurement in a clean room V Base Integrated type Measurement of clogging of bug С Exchangeable type Measurement of dynamic pressure at ventilation/exhaust device Н Scale setting Upper limit setting L Lower limit setting *(Refer to pages 114 to 117)

When making an inquiry or placing an order, specify the above product code.

line

equipment

<Usage>

filter

Precautions

Maintenance

MS99

Specifications

Model	Integrated base type, for upper limit setting limit settin		e, for lower Exchangeable base typ g upper limit setting							
	MS99H	MS99HV MS99LV		MS99HC			MS99LC			
Pressure unit	Pa, kPa			Compatibl	e pipe	Model V				
ressure leasurement lethod	Differential pressure	method						Vinyl pipe or rubber pipe (inner diameter of 4 mm) Model C Vinyl pipe or rubber pipe (inner diameter of 6 mm) Base for resin vinyl pipe (already mounted on instrument)		
Pressure-receiving element	Diaphragm					Metallic pipe (Separately so	outer diameter of 6 Id base for metallic	± 0.1 mm) pipe is necessary.		
Contact material	Silver alloy/gold plat	ing						ner diameter 4 mm) pipe and inner sleeve		
leasured gas	Air and noncorrosive	e gas (liquid cannot be i	measured)				age 95) or push-in			
Pressure setting nethod	Setting by dial with s	cale		Terminal s	crew size		- / .	meter of φ8 or below)		
Nounting orientation	Upright or horizontal			Polarity of				ow-pressure side with		
Dperating ambient emperature	-10°C to +60°C (no	freezing allowed)		connector		"H" and "L" marks, respectively, at the piping connection part. Model V Approx. 170 g				
Dperating ambient numidity	90% RH or below (n	o condensation allowed	1)	Mass Accessorie	es	Model C Appr		old)		
Exterior material	Model V Polycar Model C Polycar	bonate bonate and polyamide		Conforming standards		UL standard UL and C-UL recognition component Requirement standard No UL508				
Ourable vibration	5 to 10 Hz, amplitude of 10 mm, 10 to 50 Hz, acceleration of 39 m/s² (two hours each for three axial directions)					File No E240648 *Acquired as open-type enclosure. RoHS directive				
Ourable impact	100 m/s ² (six times e	each for three axial dire	ctions)	Protection level Cable clamp mounting screw size		Equivalent to IP54 (at time of acquisition of cable clamp) M15 P=1				
nsulation resistance	Between terminal an megger)	d case: 20 MΩ or high	er (500 V DC							
Vithstand voltage	Between terminal an minute	d case: 1500 V AC, 50	/60 Hz, for one							
Pressure range code	Pressure range	Mounting orientation *It is necessary to specify the orientation at the time of order placement for all ranges.	Scale settin accuracy (at 23°C)	Repe	atability	Maximum operating pressure difference	Pressure-receivin element materia	•		
120 D	20–120 Pa		±5.0 Pa	±2	2 <u>0</u> Pa	25 <u>.</u> 0 Pa				
200 D	20–200 Pa		±9.0 Pa	±2	2.0 Pa	25.0 Pa				
300 D	30–300 Pa		±13.5 Pa	±3	8 <u>.</u> 0 Pa	30 <u>.</u> 0 Pa		10 kPa		
500 D	50–500 Pa	Horizontal	±22 <u>.</u> 5 Pa	±5	5.0 Pa	45.0 Pa				
1000 D	100–1000 Pa	or	±45 Pa	±	10 Pa	70 Pa	Silicone rubber			
3 E	0.3–3 kPa	Upright	±0.135 kP	a ±0.0	30 kPa	0 <u>.</u> 300 kPa				
5 E	0 <u>.</u> 5–5 kPa		±0_225 kP	a ±0.0	50 kPa	0 <u>.</u> 450 kPa		20 kPa		
10 E	1–10 kPa		±0.45 kP	a ±0.	10 kPa	0.70 kPa				
30 E	3–30 kPa		±1.35 kP	a +0.	30 kPa	3.00 kPa		50 kPa		

For use environment, refer to page 118.

Caution

Opening/closing capability [standard specification]

Load	Rated voltage	Specifications	Resistance load	Induction load
	30 V DC	Contact configuration	0.8 A	150 mA (Time constant) 7 ms
Standard load	100 V AC	SPDT (single-pole double-throw) Electric service life 100,000 times or	5 A	60 mA (Power factor)
	250 V AC		5 A	_
Minute load	30 V DC 125 V AC	more	100 mA	_

Opening/closing capability [30 V DC and lower rated voltage specification]

Load	Rated voltage	Specifications	Resistance load	Induction load
Standard load	30 V DC	Contact configuration SPDT (single-pole double- throw)	0.8 A	150 mA (Time constant) 7 ms
Minute load	30 V DC	Electric service life 100,000 times or more	100 mA	—

*To enhance the contact reliability of the contact under minute load condition, gold plating is applied to the contact surface. If the instrument is used with a voltage or current exceeding the rating at the time of use of minute load, the gold plating will be broken and the contact reliability of the contact under minute load condition will be degraded.

Under minute load conditions, do not use such a product that has been used any number of times under normal load conditions.

• In an induction load circuit, such as a relay, there is a possibility of contact problems with a contact due to back electromotive force or inrush current at the time of opening or closing. Therefore, be sure to insert a protective circuit for surge absorption, such as a diode and varistor.

If silicone gas or organic gas is contained in the measured gas, such an organic substance that may lead to defective contact of a contact that is caused by arc energy at the time of contact opening/closing. If offensive gas is contained in the measured gas, malfunctioning due to defective contact of a contact or corrosion of the internal mechanism may occur. If any of the above gases exist in the measured gas or surrounding environment, discuss the use of a model with the built-in lead switch MS61A-RA, whose contact is less subject to the external atmosphere.

Rating certified with safety standard (UL) [Standard specification]

EMRT1

MS99

List of products

Rating certified with safety standard (UL) [30 V DC and lower rated voltage specification]

ge opeenieution]					
Rating					
30 V DC-0.5 A RES					

Precautions

Application

EMT6

EMP5A

HWS15A

Accessories

Maintenance

MS99


MS99

List of products

WO81

External dimension drawing


Model MS99 V (integrated base type)




MS99


Overview of structure





Mounting orientation and range It is necessary to specify the orientation at the time of order placement for all ranges.





At time of mounting of cable clamp, protection level is equivalent to IP54.

Caution

OA-W15M-04

OA-W15M-05

OA-W15M-07

φ2-4

φ3-5

φ5-7

Nylon 66

NBR

Polypropylene

• In mounting of the cable clamp to the instrument body, the supplied locknut is not used. • When extracting the wire in the base direction on Model MS99 C (exchangeable base type), the installation is disabled because the base and the cable clamp interfere with each other.

hh

18

MS99

List of products


MS99





MS99

Example of mounting of type C base











HWS15A

EMP5A

EMRT1

Accessories

Application Precautions

Maintenance



•Even when the bases are exchanged with each other, the high-pressure side and low-pressure side polarities cannot be changed. The polarity of piping connectors are indicated with an "H" mark on the high-pressure side and an "L" mark on the low-pressure side at their respective base mounting parts.

• Base tightening torque: 1 N·m Sealing cap tightening torque: 0.5 N·m

Do not tighten to a torque that exceeds the specified value because doing so breaks the instrument body. (Refer to page 120)

MS99

List of products

WO81

WO71

FR51A

MS99

MS99S

MS61A-RA

QDP33

7 Manostar 40

MS99

List of products

WO71

Protection of switch contact WO81

○To reduce the noise generated at the time of opening/closing of the load and lengthen the service life of the contact by decreasing the generation of nitric acid gas and carbide, a contact protection circuit is used. However, it will have an opposite effect if it is not used correctly.

Representative examples of a contact protection circuit

OWhen a contact protection circuit is used, the operation time of the load may be slightly delayed. Representative examples of a contact protection circuit are provided below.

FR51A	Circuit example		Applicable power source		er Points to note when applying/selecting circuit	
	Varistor method		DC	AC		
MS99 MS99S			0	0	 This method prevents a voltage equal to or exceeding the varistor's limit voltage from being applied between the contacts. In this method, the return time of the induction load on the relay is slightly delayed. From the selection materials from varistor manufacturers, select a varistor with a rating that matches the power voltage and load capacity. 	
MS61A-RA	R Induction Induction I and I and	C/R method	0	0	 In this method, the operation/return time is slightly delayed if the load is an induction load such as relay. The CR values should be around C: 0.5 μF/A and R: 1.0 Ω/V with respect to the contact current and contact voltage, respectively, as a guide. However, as these values vary depending on the property of the load and other conditions, check the values through experiment and select an appropriate model. 	
QDP33 EMD8A	A linduction load	Diode method	0	×	In this method, the back electromotive force of the induction load is canceled by the load resistance through a diode to prevent high voltage from being applied between contacts. In this method, the return time of induction load is more delayed compared to the varistor type and CR method. Select a diode whose rating current is equal to or greater than the load current and whose reverse breakdown voltage is 10 times the power voltage or greater.	
EMD7	A Induction ↓ Joad	Diode + Zener diode method	0	×	The diode method is effective when the return time of the induction load on the relay is excessively delayed. Select a Zener diode whose Zener voltage is almost equal to the power voltage as a guide. However, if the load increases, a Zener diode whose reverse surge power is great is required. Therefore, this method has a limit, and attention needs to be paid when selecting this method.	

Examples of bad contact protection circuit

EMTGP1		C Induction load		OThis method is very effective for extinction of an arc at the time of release of the contact, but the charging current flows to the condenser when contacting the contact, making the contact likely to be welded and shortening the contact service life.
EMT1H		Condenser method	OThis method is very effective for extinction of an arc at the time of release of the contact,	
EMT6				but short-circuit current in power storage capacity stored in the condenser flows when contacting the contact, making the contact likely to be welded and shortening the contact service life.

EMP5A

EMT1

EMRT1

HWS15A

Accessories

Application

Precautions

Maintenance

41 🍞 Manostar

Notes on contact material

MS99

Cautior

To enhance the contact reliability of the contact under minute load condition, gold plating is applied to the contact surface. If the instrument is used with a voltage or current exceeding the rating at the time of use of minute load, the gold plating may break, and the contact reliability of the contact under minute load conditions may degrade.

Under minute load conditions, do not use such a product that has been used any number of times under normal load conditions.

Configuration of switch contact

- The contact configuration of this instrument is as shown on the right.
- The state in which the differential pressure (pressure) is not applied to the instrument is 0 referred to as normal condition.
- In the normal the condition, the section between contact 1 (COM) and contact 2 (N.C.) is closed, and the section between contact 1 (COM.) and contact 3 (N.O.) is open.
- When the differential pressure increases and reaches the set pressure, the contact is switched, the section between contact 1 (COM.) and contact 2 (N.C.) turns to be open, and the section between contact 1 (COM.) and contact 3 (N.O.) turns to be closed.

Upper limit setting and lower limit setting

The pressure at which the electric contact of the switch is triggered as the differential pressure (pressure) applied to the instrument has increased from zero is referred to as the set pressure. Then, the pressure at which the contact has returned to the former state as the differential

pressure has decreased from the use condition at a pressure greater than the set pressure and the electric contact has been triggered is referred to as the reset pressure.

The set pressure and reset pressure mentioned above are not the same values but are slightly different from each other. This difference is referred to as the operating pressure difference (dead band).

It is not possible to change from the upper limit setting to the lower limit setting and vice versa.

This instrument has two variations: one with the scale of setting dial set to the set pressure; and the other with the scale set to the reset pressure.

This instrument with the scale set to the set pressure is referred to as the instrument for upper limit setting and the instrument with the scale set to the reset pressure is referred to as the instrument for lower limit setting.

When the setting pressure is set to 1 kPa in the pressure range of 1 to 10 kPa as an example (the operating pressure difference is assumed to be 0.7 kPa)

Scale setting	Setting dial scale adjustment	Contact action		
Instrument for upper limit setting	Adjustment is made by means of set pressure.	When the differential pressure increases, the section between 3 (N.O.) and 1 (COM.) closes at 1 kPa. Then, when the differential pressure decreases, the section between 3 (N.O.) and 1 (COM.) opens at 0.3 kPa.		
Instrument for lower limit setting	Adjustment is made by means of reset pressure.	When the differential pressure increases, the section between 3 (N.O.) and 1 (COM.) closes at 1.7 kPa. Then, when the differential pressure decreases, the section between 3 (N.O.) and 1 (COM.) opens at 1 kPa.		

Reset time

Caution

Reset time refers to the time it takes to reach the reset pressure (the electric contact is reset) when the differential pressure is suddenly reduced to zero from the set pressure. In this instrument, the reset time is approx. 3 seconds at 20 Pa and approx. 1 second at 50 Pa and greater. (However, the reset time is for the instrument body only, not including the pipe.) Therefore, a response faster than this time is impossible.

Contact rating


If the contact capacity in the specification is exceeded, additionally connect the secondary relay. In general, the smaller the voltage and current are, the longer the contact service life is. A Manostar switch cannot directly shut off a circuit whose voltage exceeds 250 V AC.

Measured gas

If offensive gas (nitric acid, hydrogen sulfide, sulfurous acid, ammonia, chlorine, etc.) is contained in the measured gas, malfunctioning due to defective contact of a contact or corrosion of the internal mechanism may occur. If the measured gas is highly humid, nitric acid may be produced due to an arc at the time of opening/closing of the contact, which may lead to similar defective contact or malfunctioning. Therefore, avoid the use of highly humid measured gas.


If the measured gas contains silicone gas generated from silicone (oil, grease, filler, etc.), silicone oxide may be generated and accumulated at the contact due to an arc at the time of opening/closing of the contact, which may lead to defective contact of a contact. Therefore, remove the silicone gas generation source or implement arc suppression measures.

1(COM.) 3(N.O.) re es. Differ 2(N.C.) a c





MS99





Eľ	M	D	7



EMP5A

EMRT1

HWS15A

Accessories

Application

Precautions

Maintenance

List of products

WO81



MS99

MS99S

MS61A-RA

QDP33

EMD8A

Warranty

Warranty period

The warranty period for our product is one (1) year from delivery to the location specified by the orderer who makes a direct transaction with us.

Scope of warranty

If any failure or defect attributable to us becomes clear during the above warranty period, we will repair the product or supply a substitute product free of charge. However, even during the warranty period, we will exclude the product from the scope of the warranty if the failure or defect corresponds to any of the following:

- (1) The failure or defect was caused by an unreasonable condition, environment, handling, or usage not mentioned in the
- instruction manual, specifications, and our product catalog.
- 2) The failure or defect was caused by a factor other than our product.
- (3) The failure or defect was caused by a modification or repair conducted by a party other than us.
- (4) The failure or defect was caused by an event that could not be foreseen at the scientific and technical levels at the time of product shipment from us.
- (5) The failure or defect was caused by an external factor not attributable to us, such as acts of God and disasters.

Please note that the warranty mentioned here means the warranty for our individual product, and damage provoked by a failure or defect of the product is excluded from the scope of the warranty.

*This warranty is valid only in Japan.

Application and usage

Our products are designed and manufactured as general-purpose instruments for general industries. Therefore, our products are not intended for the following uses, and our products used in such a manner are outside the scope of application.

- (1) Equipment that is anticipated to greatly affect lives and properties, such as nuclear power generation, aviation, railways, marine vessels, vehicles, and medical devices
- (2) Utilities that include electricity, gas, and service water
- (3) Use in outdoor locations and under similar conditions or environments other than those stipulated in the instruction manual
- (4) Usage to which considerable safety consideration and attention equivalent to (1) and (2) above need to be given

Service

Scope of service

Because the product price does not include service expenses, such as the dispatch of engineers, we will separately charge for the expenses in the following cases:

(1) Instruction for installation and adjustment and a witnessed test run

- (2) Maintenance inspection, adjustments, and repairs
- (3) Technical guidance and technical education
- (4) Witnessed inspections of products at our factory

<<Note>> The product specifications and information in this catalog are subject to change without prior notice for product improvement or other reasons.

For order placement, contact



1-2-3 Nishishiriike-cho, Nagata-ku, Kobe City, Hyogo 653-0031 TEL. +81-78-621-7000 FAX. +81-78-621-7788



1-2-3 Nishishiriike-cho, Nagata-ku, Kobe City, Hyogo 653-0031 TEL. +81-78-631-6000 FAX. +81-78-631-6020