


Accessories

Pitot tube


RoHS

Simplified model For measurement of static air pressure at indoor location, etc.


Simplified Pitot tube (simplified static pressure pipe)




For vinyl pipe



| Item number | Material | Panel cutting |
|---------------|-----------------|---------------|
| PTK—VT6—110 | Brass/steel | φ10.5 |
| PTK—VT6—110—S | Stainless steel | |




| Item number | Material | Panel cutting |
|-------------|-----------------------|---------------|
| PTK—VT4—110 | Brass/phosphor bronze | φ6.5 |




| Item number | Material | Panel cutting |
|-------------|-----------------------|---------------|
| PTK—VT4—40 | Brass/phosphor bronze | φ6.5 |

For metallic pipe



| Item number | Material | Panel cutting |
|---------------|-----------------|---------------|
| PTK—MT6—110 | Brass/steel | φ10.5 |
| PTK—MT6—110—S | Stainless steel | |


PT base



The tube mounting part is a push-in joint.
For piping, use the separately sold tube (refer to page 112)
or a tube compatible with JIS B 8381-1. (Connectable tube
outer diameter: 6)

| Item number | Material | Panel cutting |
|-------------|-------------------|---------------|
| PTK—PT6—110 | PBT, brass, steel | φ10.5 |

PR base



The tube mounting part is a rotary elbow push-in joint.
For piping, use the separately sold tube (refer to page 112)
or a tube compatible with JIS B 8381-1. (Connectable tube
outer diameter: 6)

| Item number | Material | Panel cutting |
|-------------|-------------------|---------------|
| PTK—PR6—110 | PBT, brass, steel | φ10.5 |

List of
products

WO81

WO71

FR51A

MS99

MS99S

MS61A-RA

QDP33

EMD8A

EMD7

EMT1

EMTGP1

EMT1H

EMT6

EMP5A

EMRT1

HWS15A

Accessories

Application







Precautions

Maintenance

How to use the Pitot tube

Guide for Pitot tube installation location

Depending on the pipe layout, the flow may be disturbed, which may affect the measurement accuracy. Therefore, when installing a Pitot tube, we recommend securing a sufficient straight pipe length equal to or greater than the corresponding value in the table below.

|  Pitot tube installation location D: Duct diameter Round duct D = duct inner diameter Square duct D = (duct inner width + height) / 2 | Dimension on upstream side (L1) | | Dimension on downstream side (L2) |
|---|---------------------------------|----|-----------------------------------|
| | Without flow straightener | | |
|  <p>90° bend or single tee</p> | 6D | 4D | |
|  <p>Two or more 90° bends on the same plane</p> | 10D | 4D | |
|  <p>Two or more 90° bends on different planes</p> <p>(There must be a distance of 5D or greater between two bends.)</p> | 19D | 4D | |
|  <p>Shrinking pipe or expanding pipe</p> | 6D | 4D | |
|  <p>Gate valve, fully open</p> | 12D | 4D | |

List of products

WO81

WO71

FR51A

MS99

MS99S

MS61A-RA

QDP33

EMD8A

EMD7

EMT1

EMTGP1

EMT1H

EMT6

EMP5A

EMRT1

HWS15A

Accessories

Application

Precautions

Maintenance

Warranty

■ Warranty period

The warranty period for our product is one (1) year from delivery to the location specified by the orderer who makes a direct transaction with us.

■ Scope of warranty

If any failure or defect attributable to us becomes clear during the above warranty period, we will repair the product or supply a substitute product free of charge. However, even during the warranty period, we will exclude the product from the scope of the warranty if the failure or defect corresponds to any of the following:

- (1) The failure or defect was caused by an unreasonable condition, environment, handling, or usage not mentioned in the instruction manual, specifications, and our product catalog.
- (2) The failure or defect was caused by a factor other than our product.
- (3) The failure or defect was caused by a modification or repair conducted by a party other than us.
- (4) The failure or defect was caused by an event that could not be foreseen at the scientific and technical levels at the time of product shipment from us.
- (5) The failure or defect was caused by an external factor not attributable to us, such as acts of God and disasters.

Please note that the warranty mentioned here means the warranty for our individual product, and damage provoked by a failure or defect of the product is excluded from the scope of the warranty.

*This warranty is valid only in Japan.

Application and usage

Our products are designed and manufactured as general-purpose instruments for general industries.

Therefore, our products are not intended for the following uses, and our products used in such a manner are outside the scope of application.

- (1) Equipment that is anticipated to greatly affect lives and properties, such as nuclear power generation, aviation, railways, marine vessels, vehicles, and medical devices
- (2) Utilities that include electricity, gas, and service water
- (3) Use in outdoor locations and under similar conditions or environments other than those stipulated in the instruction manual
- (4) Usage to which considerable safety consideration and attention equivalent to (1) and (2) above need to be given

Service

■ Scope of service

Because the product price does not include service expenses, such as the dispatch of engineers, we will separately charge for the expenses in the following cases:

- (1) Instruction for installation and adjustment and a witnessed test run
- (2) Maintenance inspection, adjustments, and repairs
- (3) Technical guidance and technical education
- (4) Witnessed inspections of products at our factory

<<Note>> The product specifications and information in this catalog are subject to change without prior notice for product improvement or other reasons.

● For order placement, contact

General
agent



Manostar Co., Ltd.

1-2-3 Nishishiriike-cho, Nagata-ku, Kobe City, Hyogo 653-0031
TEL. +81-78-621-7000 FAX. +81-78-621-7788

Manufacturer

Yamamoto Electric Works Co., Ltd.

1-2-3 Nishishiriike-cho, Nagata-ku, Kobe City, Hyogo 653-0031
TEL. +81-78-631-6000 FAX. +81-78-631-6020