Explosion-proof performance

MS99S

List of products

Type examination pass No. TC22339X

WO81

Intrinsically safe micro differential pressure switch

RoHS

WO71

FR51A

MS99

MS61A-RA

QDP33

EMD8A

EMD7

EMT1

EMTGP1

EMT1H

EMT6

EMP5A

EMRT1

HWS15A

Accessories

Application

Precautions

Maintenance

spark generated under normal conditions or in the event of an accident or temperature rise, whose explosion-proof safety has been verified through tests or by other means by an official organization. Be sure to use this instrument in combination with a safety holder (relay barrier). (Refer to page 45)

necessary safety factor so that combustible gas will not be ignited because of an electric

Intrinsically safe refers to a model with a structure designed in consideration of the

Ex ia IIC T6 Ga



Model MS99S (Integrated base type)

<Main application fields>


- · General factory management
- equipment

 Negative pressure for dust collector/differential pressure of air conditioner
- Filter pressure loss management Precision machine manufacturing
- line

 Building air conditioning control

<Usage>

- Detection of clogging of air filterRoom pressure measurement in a
- clean room
- Measurement of clogging of bug
- Measurement of dynamic pressure at ventilation/exhaust device
- *(Refer to pages 114 to 117)



◆When making an inquiry or placing an order, specify the above product code.

◆There is no intrinsically safe micro differential pressure switch of the exchangeable base type.

MS99S

MS99S

Specifications

Succifications	Integrated base type, for upper limit setting MS99SHV			Integrated base type, for lower limit setting			
Specifications				MS99SLV			
Pressure unit	Pa, kPa	Insulation	resistance	Between terminal and case	20 MΩ or higher (500 V DC		
Pressure measurement method	Differential pressure method	Withstand voltage		Between terminal and case	megger) 1500 V AC 50/60 Hz for one minute		
Pressure-receiving element	Diaphragm	Compatible pipe Terminal screw size Polarity of piping connector					,
Contact material	Silver alloy/gold plating						
Measured gas	Air and noncorrosive gas (liquid cannot be measured)			"H" and "L" marks, respectively, at the piping connection			
Pressure setting method	Setting by dial with scale			part.			
Mounting orientation	Upright or horizontal	Mass		Approx. 190 g			
Operating ambient temperature	-10°C to +60°C (no freezing allowed)	Accessories		Cable clamp (already installed on main body), rubber bushing (two types)			
Operating ambient humidity	90% RH or below (no condensation allowed)	Conforming standard		RoHS directive			
Exterior material	Polycarbonate	Precaution	ıs	When using this product in a			
Durable vibration	5 to 10 Hz, amplitude of 10 mm, 10 to 50 Hz, acceleration of 39 m/s ² (two hours each for three axial directions)			its structure must be intrinsical When using this product, be sthe cover, cable clamp, and D	sure to mount it by attaching		
Durable impact	100 m/s ² (six times each for three axial directions)						

Explosion-proof specifications

Explosion-proof performance Applicable guidance	Intrinsically safe structure (Ex ia IIC T6 Ga) Technical Guideline 2015 compliance with international standard JNIOSH-TR-46-1:2015 JNIOSH-TR-46-6:2015	Internal inductance (Li) Internal capacitance (Ci) Equipment protection level (EPL) Protection level	Ignorable value Ignorable value Ga IP20
Intrinsically safe circuit tolerable voltage (Ui)	14.4 V	Hazardous locations where this product can be installed*	Special hazardous location Class I hazardous location
Intrinsically safe circuit tolerable current (li)	30 mA		Class II hazardous location
Intrinsically safe circuit tolerable power (Pi)	0.11 W		

^{*}In all hazardous locations, positively prevent generation of spark, which could be an ignition source, due to impact or friction on this instrument.

Pressure range code	Pressure range	Mounting orientation *It is necessary to specify the orientation at the time of order placement for all ranges.	Scale setting accuracy (at 23°C)	Repeatability	Maximum operating pressure difference	Pressure-receiving element material	Withstanding pressures of instrument body and pressure-receiving element (Refer to page 118)
120 D	20–120 Pa	Horizontal or Upright	±5.0 Pa	±2.0 Pa	25.0 Pa	Silicone rubber	10 kPa
200 D	20–200 Pa		±9.0 Pa	±2.0 Pa	25.0 Pa		
300 D	30–300 Pa		±13 <u>.</u> 5 Pa	±3.0 Pa	30.0 Pa		
500 D	50–500 Pa		±22 <u>.</u> 5 Pa	±5.0 Pa	45.0 Pa		
1000 D	100–1000 Pa		±45 Pa	±10 Pa	70 Pa		
3 E	0.3–3 kPa		±0,135 kPa	±0.030 kPa	0,300 kPa		20 kPa
5 E	0 . 5–5 kPa		±0,225 kPa	±0.050 kPa	0.450 kPa		
10 E	1–10 kPa		±0.45 kPa	±0,10 kPa	0.70 kPa		
30 E	3–30 kPa		±1.35 kPa	±0.30 kPa	3.00 kPa		50 kPa

- ◆For an overview of the structure, refer to page 38.
- ◆For contact and other materials, refer to page 42.
- ◆For the use environment, refer to page 118.

Opening/closing capability

Rated voltage	Specifications	Resistance load
12 V DC	Contact configuration SPDT (single-pole double-throw) Electric service life 100,000 times or more	30 mA

List of products

WO81

WO71

FR51A

MS99

MS99S

MS61A-RA

QDP33

EMD8A

EMD7

EMT1

EMTGP1

EMT1H

EMT6

EMP5A

EMRT1

HWS15A

Accessories

Application


Precautions

Maintenance


MS99S

List of products


External dimension drawing



Mounting orientation and range It is necessary to specify the orientation at the time of order placement for all ranges.



Terminal connection part



· Barrier relay system TBR-100 series (Takenaka Electronic Industrial Co., Ltd.)

· Safety holders that can be connected to this product are limited to such safety holders that have passed the type examination as sole devices and satisfy the following conditions.

Performance category: ia

Group: IIC

Uo ≤ 14 4 V

lo ≤ 30 mA Po ≤ 0.11 W

- For external wiring of the intrinsically safe circuit, use such wires that satisfy the wiring conditions for the safety holder
 - Lc: inductance of external wiring of the intrinsically safe circuit
 - Co ≥ Cc Cc: capacitance of external wiring of the intrinsically safe circuit
- *The internal inductance and internal capacitance of this product are not considered because they are ignorable values.
- Route the wires of the intrinsically safe circuit such that the voltage and current that may impair the intrinsic safety of the intrinsically safe circuit are not induced on the intrinsically safe circuit by electromagnetic induction and electrostatic induction.

WO81

WO71

FR51A

MS99

MS61A-RA

QDP33

EMD8A

EMD7

EMTGP1

EMT1

EMT1H

EMT6

EMP5A

EMRT1

HWS15A

Accessories

Application

Precautions


Maintenance


45 🍞 Manostar

MS99S

Accessories dedicated to MS99

RoHS








In mounting of the cable clamp to the instrument body, the supplied locknut is not used.

Accessories dedicated to S type RoH





List of products

WO81

WO71

FR51A

MS99

MS99S

MS61A-RA

QDP33

EMD8A

EMD7

EMT1

EMTGP1

EMT1H

EMT6

EMP5A

EMRT1

HWS15A

Accessories

Application 1 4 1

Precautions

Maintenance

Warranty

Warranty period

The warranty period for our product is one (1) year from delivery to the location specified by the orderer who makes a direct transaction with us.

Scope of warranty

If any failure or defect attributable to us becomes clear during the above warranty period, we will repair the product or supply a substitute product free of charge. However, even during the warranty period, we will exclude the product from the scope of the warranty if the failure or defect corresponds to any of the following:

- (1) The failure or defect was caused by an unreasonable condition, environment, handling, or usage not mentioned in the instruction manual, specifications, and our product catalog.
- (2) The failure or defect was caused by a factor other than our product.
- (3) The failure or defect was caused by a modification or repair conducted by a party other than us.
- (4) The failure or defect was caused by an event that could not be foreseen at the scientific and technical levels at the time of product shipment from us.
- (5) The failure or defect was caused by an external factor not attributable to us, such as acts of God and disasters.

Please note that the warranty mentioned here means the warranty for our individual product, and damage provoked by a failure or defect of the product is excluded from the scope of the warranty.

*This warranty is valid only in Japan.

Application and usage

Our products are designed and manufactured as general-purpose instruments for general industries.

Therefore, our products are not intended for the following uses, and our products used in such a manner are outside the scope of application.

- (1) Equipment that is anticipated to greatly affect lives and properties, such as nuclear power generation, aviation, railways, marine vessels, vehicles, and medical devices
- (2) Utilities that include electricity, gas, and service water
- (3) Use in outdoor locations and under similar conditions or environments other than those stipulated in the instruction manual
- (4) Usage to which considerable safety consideration and attention equivalent to (1) and (2) above need to be given

Service

Scope of service

Because the product price does not include service expenses, such as the dispatch of engineers, we will separately charge for the expenses in the following cases:

- (1) Instruction for installation and adjustment and a witnessed test run
- (2) Maintenance inspection, adjustments, and repairs
- (3) Technical guidance and technical education
- (4) Witnessed inspections of products at our factory

<<Note>> The product specifications and information in this catalog are subject to change without prior notice for product improvement or other reasons.

●For order placement, contact					



1-2-3 Nishishiriike-cho, Nagata-ku, Kobe City, Hyogo 653-0031 TEL. +81-78-621-7000 FAX. +81-78-621-7788



1-2-3 Nishishiriike-cho, Nagata-ku, Kobe City, Hyogo 653-0031 TEL. +81-78-631-6000 FAX. +81-78-631-6020